



Sirius Stiletto 2 Battery Replacement

This guide will show how the battery for the Sirius Stiletto 2 can be accessed and replaced.

Written By: Benjamin Her



INTRODUCTION

The maximum battery life for any battery will always decrease as the battery is used. Learning to replace the battery will allow you to make sure your device works when you need it to.

Step 1 — Battery



- From the back of the device, slide the back panel downwards to unlock the panel.
- Lift the panel up, exposing the battery.

Step 2



- Pinch the battery from both sides and lift the battery to remove it.

To reassemble your device, follow these instructions in reverse order.

